

- Burst, Puncture

### SPECIFICATIONS – EXTREME & STANDARD

# **Containment FOAM LOGS (not for sediment control)**



- Water Permeability

Thread

15-gpm/sf clean water, <1-gpm/sf dirty water

UV Resistant Polyester

Accidental cut repair

Fill cut with caulking or replace

Functional Life (expected)

2-5 years (excludes major damage)

275 psi, 65 lbs.

Date: September, 2017 – The above properties are typical averages. All test methods are ASTM or Industry Standards.

Distributed by: Bowman Construction Supply, 10801 E. 54th Avenue, Denver, CO 80239; Phone: (303) 696-8960



# **REUSABLE FOAM LOGS**

## **= DRIVEABLE BERMS - FOR CONTAINMENT**

(not for sediment control - not biodegradable)

#### DRILL PAD FULL CONTAINMENT

Use foam logs to form a perimeter berm around the edges of the liner. Wrap the liner over the log and weld the liner –

or place the foam log under the edge and secure liner to the ground.

#### SMALL EQUIPMENT CONTAINMENT

Use foam logs to form a wall around the edges of the containment. Wrap the liner over the log and weld the liner –

or weld straps to the liner walls and floor to secure the foam log as a wall support.

#### **FOAM TYPES**

STANDARD FOAM becomes egg shaped when driven over, but can easily be reformed back to round. Standard foam pieces can escape if the fabric is ripped open, or deteriorated, creating foam litter.

EXTREME FOAM keeps nearly full height when driven over, and has no foam litter if ripped open.

#### **CUT TO LENGTH**

To cut a STANDARD Foam Log, shake stuffing from desired cut location, secure two zip ties around the Log about 6-inches apart and tighten. Cut fabric with a torch, or cut with scissors and seal cut fabric with a lighter or torch.

To cut an EXTREME Foam Log, cut the fabric one foot beyond the desired log end, pull out the foam insert and cut to desired length with a big knife. Secure the cut log ends with zip ties.

#### **MAINTENANCE**

Repair cuts with caulk – stuff anything in the hole for temporary fix – pick up foam.

Dispose of Foam Logs properly if damaged, deteriorated or no longer needed.

www.gatorguard.com

1-877-GATORME

1-877-428-6763

Corporate Member