



# Application Guide for Profile<sup>®</sup> HP-FGM<sup>™</sup> and ET-FGM<sup>™</sup>

## Application / Loading Procedures

- A. Strictly comply with equipment Manufacturer's installation instructions and recommendations. Use approved hydro-spraying machines with fan-type nozzle (50-degree tip) whenever possible to achieve best soil coverage. Apply from opposing directions to assure 100% soil surface coverage. Slope interruption devices or water diversion techniques are recommended according to the slope interruption limits table on the back.
- B. To ensure proper application rates, measure and stake area. For maximum performance, apply in a two-step process\*:
  1. Apply specified prescriptive agronomic formulations along with 50% of seed with a small amount of HP-FGM<sup>™</sup> or ET-FGM<sup>™</sup> for visual metering.
  2. Mix balance of seed and apply HP-FGM or ET-FGM at a rate of 50 pounds per 125 gallons (see mixing section on the back for details) of water over freshly seeded surfaces. See loading chart on the back and confirm loading rates with equipment manufacturer. Do not leave seeded surfaces unprotected, especially if precipitation is imminent.
- C. Fill 1/3 of mechanically agitated hydroseeder with water. Turn pump on for 15 seconds and purge and pre-wet lines. Turn pump off.
- D. Turn agitator on and load low density materials first (i.e. seed).\*\*
- E. Continue slowly filling tank with water while loading fiber matrix into tank.
- F. Consult loading chart on the back to determine the number of bags to be added for desired area and application rate.
- G. HP-FGM or ET-FGM should be completely loaded before water level reaches 75% of the top of tank.
- H. Top off with water and mix until all fiber is fully broken apart and hydrated (minimum of 10 minutes — increase mixing time when applying in cold conditions). This is very important to fully activate the bonding additives and to obtain proper viscosity.
- I. Add fertilizer.
- J. Shut off recirculation valve to minimize potential for air entrainment within the slurry.
- K. Slow down agitator and start applying with a 50-degree fan tip nozzle.
- L. Spray in opposing directions for maximum soil coverage.

*\*Depending on site conditions, HP-FGM or ET-FGM may be applied in a one-step process where all components may be mixed together in single tank loads. Consult with Manufacturer for further details.*

*\*\*Do not add tackifiers or polymers.*

## Loading Chart for Profile's HP-FGM and ET-FGM

Tank Size (gal)	# of 50-lb bales	(lb)	Displacement (gal)	2,500 lb/acre		3,000 lb/acre		3,500 lb/acre		4,000 lb/acre		4,500 lb/acre	
				Sq ft	Acres	Sq ft	Acres	Sq ft	Acres	Sq ft	Acres	Sq ft	Acres
250	2	100	280	1,742	0.040	1,452	0.033	1,245	0.029	1,089	0.025	968	0.022
500	4	200	560	3,485	0.080	2,904	0.067	2,489	0.057	2,178	0.050	1,936	0.044
750	6	300	840	5,227	0.120	4,356	0.100	3,734	0.086	3,267	0.075	2,904	0.067
1,000	8	400	1,120	6,970	0.160	5,808	0.133	4,978	0.114	4,356	0.100	3,872	0.089
1,500	12	600	1,680	10,454	0.240	8,712	0.200	7,467	0.171	6,534	0.150	5,808	0.133
2,000	16	800	2,240	13,939	0.320	11,616	0.267	9,957	0.229	8,712	0.200	7,744	0.178
2,500	20	1,000	2,800	17,424	0.400	14,520	0.333	12,446	0.286	10,890	0.250	9,680	0.222
3,000	24	1,200	3,360	20,909	0.480	17,424	0.400	14,935	0.343	13,068	0.300	11,616	0.267
3,500	28	1,400	3,920	24,394	0.560	20,328	0.467	17,424	0.400	15,246	0.350	13,552	0.311
4,000	32	1,600	4,480	27,878	0.640	23,232	0.533	19,913	0.457	17,424	0.400	15,488	0.356

### Additional Notes:

- For hose applications, 35 lb/100 gal is recommended.
- Rough surfaces (rocky terrain, cat tracks, ripped soils, etc.) may require additional product to achieve 100% coverage.
- Be sure to allow for residual material in tank on subsequent applications.

Application Rates		
Slope Condition	English	SI
≤ 4H to 1V	2500 lb/acre	2800 kg/hectare
> 4H to 1V and ≤ 3H to 1V	3000 lb/acre	3400 kg/hectare
> 3H to 1V and ≤ 2H to 1V	3500 lb/acre	3900 kg/hectare
> 2H to 1V and ≤ 1H to 1V	4000 lb/acre	4500 kg/hectare
> 1H to 1V <sup>1</sup>	4500 lb/acre	5100 kg/hectare
Below ECB or TRM	1500 lb/acre	1700 kg/hectare
As infill for TRM <sup>2</sup>	3500 lb/acre	3900 kg/hectare

Slope Interruption Limits*		
Product Category	Length (ft)	Length (m)
HP-FGM	100	30
ET-FGM	125	38

\*Listed slope interruption limits are for product applications on a 3H:1V slope. For application on steeper slopes, slope interruption lengths may need to be decreased.

<sup>1</sup>HP-FGM or ET-FGM recommended for slopes greater than 1H:1V.

<sup>2</sup>Use only approved and tested TRMs to create the GreenArmor System.

### Visual Key for Proper Application (Flexterra HP-FGM shown below)

Proper Application	Improper Application	3,000 lb/acre	3,500 lb/acre	4,000 lb/acre



**Flexterra HP-FGM**

PROFILE Products LLC  
750 Lake Cook Road, Suite 440  
Buffalo Grove, IL 60089

**CocoFlex ET-FGM**

U.S. Patent #'s: 5,942,029; 5,779,782; 5,741,832; 6,360,478; 7,752,804



# LOCATIONS & CONTACT INFO

## ASP ENTERPRISES

aspent.com  
salesasp@aspent.com

## BOWMAN CONSTRUCTION SUPPLY

bowmanconstructionsupply.com  
salesbcs@bowmanconstructionsupply.com

## QUICK SUPPLY CO.

quicksupplyco.com  
salesquick@quicksupplyco.com

## CASCADE GEOSYNTHETICS

cascadageos.com  
salescascade@cascadageos.com

St. Louis, MO 636.343.4357  
Omaha, NE 402.861.8579

Denver, CO 303.696.8960  
Loveland, CO 970.535.0863

Des Moines, IA 515.289.1271

Portland, OR 971.339.1020

Kansas City, MO 816.554.1191  
Wichita, KS 316.393.1554

Colorado Springs, CO 719.257.7840

Salt Lake City, UT 435.276.0820

# SOLUTIONS WE SUPPLY

## GEOSYNTHETICS

Filter Fabrics  
Stabilization Fabrics

### Geogrids

- Road Grids
- Wall Grids
- Slope Stabilization

### Specialty Fabrics

#### Composite Geomembranes

- GCLs, PVC, HDPE, LLDPE, EPDM, Granular Bentonite

## SEDIMENT CONTROL

### Inlet Protection

- Grated Inlet, Curb Inlet, Area Inlet Protection

### Ditch Checks

- Triangle Silt Dike
- GeoRidge

### Perimeter Protection

- High and Low-Porosity Silt Fence, Straw Wattles, Silt Socks
- Safety Fence

### Flocculants & Water Treatment

- Polymer-Based & Natural Flocculants

### Sediment Basin Skimmers

### Dewatering Bags

### Trackout Control

- FODS
- Rumble Grates

### Turbidity Curtains

## EROSION CONTROL

### Basic Hydraulically Applied Mulches

- Wood
- Paper
- Blends
- Straw

### High-Performance Hydraulically Applied Products

- BFM
- FGM
- Additives & Tackifiers

### Temporary Erosion Control Blankets

- Coir & Jute Mat/Nettings
- Short-Term ECBs
- Extended-Term ECBs

### Permanent Erosion Control Blankets

- Turf Reinforcement Mats
- HP-TRMs
- Anchor Reinforced Vegetation System

### Structural BMPs

- Transition Mats
- Geoweb Cellular Confinement
- Composite Vegetated Armor System
- Flex MSE Vegetated Wall System
- Articulated Concrete Block
- Gabions
- Grout-Filled Geotextile Mats

### Vegetation Establishment

- Native Seed & Turf Seed
- Fertilizers
- Organic Soil Additives
- Stratavault Soil Cells

## STORMWATER MANAGEMENT

### Water Quality

- Inlet Filter Boxes
- Pre-Treatment Chamber
- Nutrient Separating Baffle Boxes
- High-Flow Biofiltration Media
- Hydrodynamic Separators
- Stratavault

### Water Quantity

- Modular Underground Storage Systems
- Chamber Detention Systems

### Drainage

- HDPE Swale Liner
- Pipe & Fittings
- Drainage Composites
- Strip Drain

### Inlet Structures

- PVC
- Drain Basis, In-Line Drains
- Landscape

### Permeable Pavers

- Permeable Articulating Concrete Block
- Grass Pavers
- Gravel Pavers
- Concrete Pavers

## SPECIALTY

### Natural & Synthetic Coir Fiber Logs

### Vegetated Reinforced Soil Slopes

### Soil Anchors

### Root Barrier System

### AquaBlok

### Muscle Wall

We are full line distributors of construction materials for all project types. Contact us for assistance with a project. From specification and development to installation and completion, we're here to help with all of your site solution needs.

**GEOSYNTHETICS | EROSION CONTROL | STORMWATER MANAGEMENT  
SEDIMENT CONTROL | REVEGETATION & SOIL AMENDMENTS**